

SURFACE PREPARATION

Surface preparation is a crucial step in optimizing the performance of any coating system.

Plaster, concrete, cement, rendering, brickwork...etc.

Surfaces should be free from dirt, loose material efflorescence...etc. On all new material, allow surface to dry out completely before painting. For old surfaces, treat all cracks and minor surface damage with appropriate filler and leave to drying before priming.

Woodwork

Clean to remove dirt and contamination. Rub down with fine to medium glass paper. Prime with Eagle Paints then proceed to full painting system.

Steel

Remove traces of salt and contamination by hosing down with water and detergent, if necessary. Rust and loose paint must be thoroughly removed by a wire brush or mechanical grinding. For major works, blast-cleaning is a must.

Brushes and rollers are the most frequently used, whether separately or combined, and should be selected according to requirements